




Sun Amplifier Set Up Software

Sun's Amplifier Set Up Software was developed to simplify system configuration using a PC. Instead of tuning small potentiometers and switches, Sun's Amplifier Set Up Software allows you to set and monitor parameters with common terms and standard units. After connecting an IR adapter to your PC and attaching it to an energized amplifier, simply scroll through to the desired parameter and view or adjust the setting. The Amplifier Set Up Software also offers the ability to read all parameters with one operation. The parameters can then be viewed on the screen in table form and saved to a file for future use. The settings list can then be written to another device for duplication, backup, etc. The table of settings can also be printed for a hard copy record. These features make the Amplifier Set Up Software an easy, effective way to communicate with Sun embedded amplifiers.



Installation:

Please follow these steps to install the Amplifier Set Up Software:

Note: The Sun Amplifier Set Up Software is also available for download off of Sun's website.

1. Insert the Flash Drive (P/N: 991-908).
2. Choose "Open folder to view files" or view the appropriate drive in Windows Explorer.
3. Install the required USB drivers by double clicking the appropriate file. For 32 bit Windows choose **drvinst32.exe** or for 64 bit Windows choose **drvinst64.exe**.
4. Follow the prompts for the driver installation.
5. Next, double click **setup.exe** to install the software.
6. Follow the prompts for the software installation.
7. The software will start when the installation completes. Please view the help files for instructions on using the software.